


Cassette® C223 CS



Key No.	Part No.	Description
1	20095062	Seat and Cover
2	16833	Vacuum Breaker
3	20095262	Flush Tube and Nozzle
4	23709	Electric Valve, Hose Nut & Hose Barb
5	200956	<i>Level Indicator Lens</i>
6	200957	Level Indicator
7	200962	PCB
8	20097462	Control Panel and Sticker
9	200975	Seal Base Wall

 Not available