





		Spare part number
1	Door latch	693042
2	Control panel	693057
3	Shelf	693045
4	Shelf clip - small	692759
5	Shelf food retainer	693061
6	Door switch	692641
7	Thermistor Thermistor cover	692776
8	Freezer door	693062
9	Upper drawer	693063
10	Divider upper drawer	693052
11	Slider set upper drawer	693055
12	Winter lock bracket	693044
13	Winter lock	
14	Slider set bottom drawer	693069
15		
16	Fan cover	693048
17	Fan	692785
18	Bottom lock plate (1x)	693054
19	Foot set (4x)	693047
20	Door handle	693040
21	Door lock rod (1x)	693049
22	Cabinet Door	693059
22a	Door panel	692984
23	Door bin	693043
24	Screw cap (6x)	693060
25	Bottom drawer	693050
26	Divider bottom drawer	693053
27	Panel retainer	693058
28	Main control board (PCB)	693041
29	Main control housing	
30	Compressor control module	693056
31	Vent	693051
<i>not depicted</i>	Power cord	693046
<i>not depicted</i>	Solenoid valve	692787

XXXXXX = not available anymore

Note Identification Label

With a request for information or service, always provide the serial number of the refrigerator. The serial number is the code below the barcode on the identification label.

