



| | | Spare number | | |
|-----|------------------------------|------------------|------------------------------|------------------------------|
| 1 | Hinge pin | | | |
| 2 | Retaining ring | 35788 | 35782 | |
| 3 | Cover | | | 35778 |
| 4 | Seal | 08166 | | |
| 5 | Hinge left hand | | 35787 | |
| 6 | Hinge right hand | 35783 | | |
| 7 | Seat | | | |
| 8 | Cap | | | |
| 9 | Splash guard | | 35779 | |
| 10 | Cover & bowl | | | |
| 11 | Vinyl skirt | 03984 | | |
| 12 | Inlet tube | 03946 | | |
| 13 | Base molding left | | | |
| 14 | Main housing | | | |
| 15 | Main housing seal | 35781 | | |
| 16 | Slide ez valve | | | |
| | <i>with handle</i> | 35770 | | |
| | <i>with longer shaft</i> | 35771 | | |
| | <i>short shaft with hole</i> | 35769 | | |
| | Seal valve | 01436 | | |
| | Seal valve | 01457 | | |
| | Seal repair package | 09872 | | |
| 17 | Screw | | | 35776 |
| 18 | Closet flange seal | 24304 | | |
| 19 | Nut | | 12524 | |
| 20 | Closet bolt | | | |
| 21 | Handle | | 35780 | |
| 22 | Retaining ring | | | |
| 23 | Slide hold downs (2x) | | | |
| 24 | Mounting bracket | | | |
| 25 | Screw | | | |
| 26 | Base molding right | | | |
| 27 | Filter cone | 35773 | | |
| 28 | Pump | 35784 | 35774 pump & motor 12V | 35775 pump & motor 24V |
| | Motor 12V | 35785 | | |
| | Motor 24V | 35786 | | |
| 29 | Screw | | | |
| 30 | Screw | | | |
| 31 | Gasket | 03928 | | |
| 32 | Screw | | | |
| 33 | Lock washer | | | |
| 34 | Nut | | | |
| 35 | Grommet | | 35772 | |
| 36 | Level indicator | | | |
| 37 | Cable | | | |
| 38 | Motor cover | | | |
| 39 | Screw | | 35777 | |
| 40 | Boot switch | 12032 | | |
| N/A | Switch push button | 35789 | | |

xxxxxx = not available anymore