



LE1453\_SHB162XX

		Spare part number	Colours available
1	Glass lid	<i>Refer to page 3</i>	
2	Hinges set	SSPA0010	
2A	Lid Shut-off switch (1x)	SSPA0611	
3	Pan support medium	SSPA0965	
4	Pan support large	SSPA0953	
5	Burner assembly large / rapid		
	Production date: < 16/03/15 (E074S...)	SSPA0120	
	Production date: ≥ 16/03/15 (E075S...)	SSPA0124	
6	Burner assembly medium / semi-rapid		
	Production date: < 16/03/15 (E074S...)	SSPA0111	
	Production date: ≥ 16/03/15 (E075S...)	SSPA0110	
7	Bump stop set	SSPA0040	
8	Bezel	SSPA0075	
9	Control knobs	<i>Refer to page 3</i>	
10	Ignition switch and wire harness set		
	Production date: < 16/03/15 (E074S...)	SSPA0331	
	Production date: ≥ 16/03/15 (E075S...)	SSPA0332	
11	Gas tap burner		
	Production date: < 16/03/15 (E074S...)	SSPA0427	
	Production date: ≥ 16/03/15 (E075S...)	SSPA0426	
12	Thermocouple		
	Production date: < 16/03/15 (E074S...)		
	Left	SSPA0675	
	Right	SSPA0676	
	Production date: ≥ 16/03/15 (E075S...)		
	Left	SSPA0680	
	Right	SSPA0682	
13	Spark electrodes set		
	Production date: < 16/03/15 (E074S...)	SSPA0310	
	Production date: ≥ 16/03/15 (E075S...)	SSPA0320	
14	Spark generator	SSPA0302	
15	Worktop fixing Kit	SSPA0021	

**Glass lid**

Spare part number	Colours available	
SSPA0200	<del>Solid black</del> Clear	

**Control knobs**

	
<b>Spare part number</b>	SSPA0920
<b>Colours available</b>	Black (.BK)
<b>Set quantity</b>	3

~~xxxxxx~~ = not available anymore