


LE1456\_SHB167XX


		Spare part number	Colours available
1	Glass lid	<i>Refer to page 3</i>	
2	Hinge	SSPA0010	
2A	Lid Shut-off switch (x1)	SSPA0611	
3	Pan rest medium	SSPA0965	
4	Burner Assembly Medium		
	Production date: ≤ 15/03/15 (E074S...)	SSPA0114	
	Production date: ≥ 16/03/15 (E075S...)	SSPA0812	
5	Burner Assembly Small		
	<del>Production date: ≤ 15/03/15 (E074S ...)</del>	<del>SSPA0103</del>	
	Production date: ≥ 16/03/15 (E075S ...)	SSPA0811	
6	Bump Stop set	SSPA0040	
7	Bezel	SSPA0075	
8	Control knobs	<i>Refer to page 3</i>	
9	Ignition switch and wire harness set		
	Production date: ≥ 16/03/15 (E075S ...)	SSPA0335	
10	Gas tap burner 2x medium		
	<del>Production date: ≤ 15/03/15 (E074S ...)</del>	<del>SSPA0427</del>	
	Production date: ≥ 16/03/15 (E075S ...)	SSPA0425	
	Gas tap burner 1x large, 1x medium		
	<del>Production date: ≤ 15/03/15 (E074S ...)</del>	<del>SSPA0428</del>	
	Production date: ≥ 16/03/15 (E075S ...)	SSPA0426	
11	Thermocouple		
	Production date: ≤ 15/03/15 (E074S ...)	SSPA0163	
	Production date: ≥ 16/03/15 (E075S ...)	SSPA0680	
12	Spark electrode set		
	Production date: ≤ 15/03/15 (E074S ...)	SSPA0310	
	Production date: ≥ 16/03/15 (E075S ...)	SSPA0320	
13	Spark Generator	SSPA0300	
14	Fixing Kit	SSPA0021	

xxxxx= not available anymore

**Glass lid**

Spare part number	Colours available	
SSPA0200	Clear	

**Control knobs**



<b>Spare part number</b>	SSPA0920
<b>Colours available</b>	Black (.BK)
<b>Set quantity</b>	3